

















COMPOSITION TABLES 1 AUDIO DOOR PHONE COLUMN WITH 1 AUDIO ENTRY PANEL



2VOICE AUDIO SYSTEM ON SYNTHESI

NUMBER OF BUTTONS	1083/7	1145/62	1145/63	1145/64	1145/11	1145/12	1145/13	1145/14	1145/50	1145/52	1145/53	1145/54	1038/17	1083/20	Basic door phone 1183/1 or comfort door phone 1183/2 or with additional buttons 1183/3
															
2	1	1								1				1	2
3	1		1		1						1		1	1	3
4	1		1			1					1		1	1	4
6	1		1					1			1		1	1	6
8	1	2				1		1		2			1	1	8
9	1			1			1	1				1	1	1	9
10	1			1				2				1	1	1	10
12	1		2			1		2	1		2		1	1	12
14	1		2					3	1		2		1	1	14
15	1		2		1			3			2		1	1	15
16	1		2			1		3			2		1	1	16
18	1		2					4			2		1	1	18
20	1			2		1		4	1			2	2	1	20
21	1			2			1	4	1			2	2	1	21
22	1			2				5	1			2	2	1	22
24	1			2		1		5				2	2	1	24
27	1		3		1			6			3		2	1	27
28	1		3			1		6			3		2	1	28
30	1		3					7			3		2	1	30